


## BERKOL® Maintenance Machines



### BERKOLUBE

Pneumatic top roller lubrication unit for the service workshop. All axially lubricated top rollers can be maintained.



### Electro-hydraulic press APH50-H500EV

For fitting and removing long Alupress covers on the top rollers of preparatory machines and combers.



### Lubricating unit BOS-01

Manual lubricating unit for all common ring spinning and flyer top rollers.



### Roughness tester

Makes regular monitoring of the defined roughness standard quick and easy.



### Pneumatic press PP125-H100

For fitting and removing short Alupress covers on ring spinning, roving, air jet top rollers and OE delivery top rollers.



### Shore A hardness tester HPSA R35M

Durometer according to Shore A for determining and monitoring the surface hardness of cots and pressure rollers.



### Concentricity tester

Tests the concentricity and parallelism of top rollers and bearing journals.